



# STENTEN'S INSTRUCTIONS



## INSTALLATION INSTRUCTIONS

MS2043US & MST2043US

Enclosure

Club Car Precedent w/Ultra Seal



### Track Installation

1. Remove the windshield and any accessories attached to the front top struts.
2. Locate and remove the first bolt from the top strut and the top.
3. Remove the two bolts holding the handle to the roof.
4. Use the 2 ¼ "bolt and the ½ "spacer provided to replace the first bolt.
5. Mount the track using the first bolt and the nylock nut.
6. Repeat the procedure to mount the track along the handle. The track should be pushed out toward the outer edge of the roof. See figure 1.1
7. Attach smaller bent track along rear of roof facing forward on the plastic extension. Install using two ½ "machine screws provided with track. See figure 1.2
8. It may be necessary to bend the back portion of the side track inward so the enclosure panels meet at the rear.

### Sleeve Installation

1. With the windshield removed. Wrap the sleeve around the windshield frame so that the cut out for the windshield retention clip is in the proper position.
  - a. NOTE: THERE IS A SMALL HOLE IN THE SLEEVE FOR THE LOWER WINDSHIELD BOLT
2. Engage the smaller zipper so that it wraps snugly around the windshield frame. The zipper should be on the back side of the windshield frame.
3. Attach the windshield by carefully snapping the windshield extrusion around sleeve and frame.

### Enclosure & Rain Guard Installation

1. Push the upper edge of the Rain Guard under the rear portion of the roof and engage the c-clamps around the bag hoop.
2. Insert the 3 ½" bolts with a washer on top and a washer on the bottom tighten nylock nut.
3. Locate the bead portion on the upper edge of the enclosure.
4. Beginning from the front feed in the bead and pull toward the rear of the car.
5. Locate smaller rear panel, the "Ultra Seal", and insert bead portion into track until it aligns with previously inserted panels.
6. Zip side panels to rear "Ultra Seal" panel. The bottoms of the "Ultra Seal", that have the extrusion, slide behind the seat backs and attach under the seat bottom.
7. Place "Rain Guard" on bag hoop support. Using provided bolts tighten until securely fastened. See figure 1.3



# STENTEN'S INSTRUCTIONS

## Figures

