



STENTEN'S INSTRUCTIONS



INSTALLATION INSTRUCTIONS

MS2853 & MS2933

Enclosure

Club Car DS 1982 – 2000 ½



1. Remove the rails and the hardware package that is taped in the top of the box.
2. Remove the enclosure from the box and lay it out so you can familiarize yourself with the different pieces.
3. Remove the windshield from your cart and attach the no=Velcro sleeves to the appropriate side of the cart.

Sleeve Installation

- a. With the windshield removed.
- b. Wrap the sleeve around the windhshield frame and engage the smaller zipper so that it wraps snugly around the frame. The zipper should be on the back side of the windshield frame.

Track Installation

4. Note: All rails should be installed with the bead pointing down and to the outside of the cart. The front edge of the enclosure should line up with the windshield frame.
5. Club Car 1982-2000 ½: Drill (3) $\frac{1}{8}$ " holes in the side rails (1-2" from each end and 1 – in the middle). Zip the curtains on one side together and then zip them to the front sleeve. Slide the aluminum track onto the curtains with the bead pointing down and to the outside of the cart. With the front edge of the curtains lined up with the windshield and hanging properly drill through the top and attach (3) pop rivets in the pre-drilled holes. With the curtains zipped to the front sleeve and hanging properly crimp the ends of the rails so the curtain will not move. Do the other side in the same manner.
6. Rear curtain: Center the short rail along the inside edge of the roof of the golf car with the opening pointing out and down and attach using the pop rivets provided. If you have a Club Protector w/ cold curtain, there will be 2 rails to be attached back to back using the same rivets. One rail with the bead pointing down and out and the other rail with the bead pointing down and in.
7. If your enclosure has body snaps install the male portion of the snaps on the body of the cart using the pop rivets provided. The enclosure should be snug but not to tight.



STENTEN'S INSTRUCTIONS

Club Protector

- a. Put Club Protector onto cart. Carefully slide top (beaded) end of Club Protector cover through the rear rail. Slowly open the Club Protector making sure that the main frame bar rests on the lower cart basket/bag support frame.
- b. Attach Club protector Mainframe bar onto the cart basket/bag support frame. If your Club Protector Mainframe bar aligns with existing bolts, remove them. If it doesn't you must mark and drill two holes using a ¼" drill bit through the outside slots of the mainframe bar. Attach with bolts and nuts provided. Use spacers if needed.

Note: If the cover appears to be tight, place the appropriate Club Protector spacers under the Club Protector Main Frame Bar so the bar rests on the spacers instead of the cart basket/bag support bar. The spacers relieve tension in the cover.

8. Re-attach the windshield by carefully snapping the windshield extrusion around the sleeve and frame.