



# STENTEN'S INSTRUCTIONS



## INSTALLATION INSTRUCTIONS

MST2603 & MST2603NVC

Enclosure

Club Car DS 2000 & Newer



1. Remove the rails and the hardware package that is taped in the top of the box.
2. Remove the enclosure from the box, and remove the Velcro from the leading edge of both the front doors. If you have the no Velcro enclosure please remove the windshield and install tube attachment to windshield frame per the instructions.
3. Place the short rail along the inside edge of the roof of the golf car with the opening pointing out and down.
4. Use the existing bolts for the rear strut attachment. To attach the front use 2 pop rivet to the front edge of the windshield frame, just below the plastic part for the windshield frame.
5. Drill a 1/8" hole in center of the rail and the edge of the golf car roof. Insert a rivet through the rail and the edge to secure the rail to the top. Repeat at each end of the rail.
6. Install the side rails in similar manner being sure that the front edge of the enclosure will line up with the windshield frame when all is complete.
7. Remove paper backing from the top edge of Velcro. Attach it to the upper edge of the post and work downward removing the paper backing as necessary.
8. If your enclosure has body snaps follow the same procedure for attaching the snaps to the body as you did for the rails.
9. The enclosure should be snug but not tight.